

**CONSOMMABLES POUR IMPRIMANTES
ET PHOTOCOPIEUR**

MARS 2017

EPSON®

CARTOUCHES EPSON



Référence	Désignation	Prix TTC
ET1801		79
ET1802	Expression Home XP-30/102/202/205/302/305/402/405/405WH/212/215/312/315/412/415 = XP-225/322/325/422/425	79
ET1803		79
ET1804		79
ET1811		AR
ET1812	Expression Home XP-30/102/202/205/302/305/402/405/405WH/212/215/312/315/412/415	79
ET1813		79
ET1814		79
ET1281		59
ET1282	Stylus S22/SX125/SX130/SX230/SX235W/SX420W/SX425W/SX430W/SX435W/SX438W/SX440W/SX445W Office BX305F/BX305FW	59
ET1283		59
ET1284		59
ET0711		55
ET0712	EPSON Stylus D78/D92/D120/DX4000/DX4050/DX4400 DX4450/DX5000/DX5050/DX6000/DX6050/DX7000F DX7400/DX7450/DX8400/DX8450/DX9400F/S20/S21 SX100/SX110/SX105/SX115/SX200/SX205/SX209/SX210 SX215/SX218/SX400/SX405/SX405WiFi/SX410/SX415/SX510W/SX515W/SX600FW/SX610FW/BX600FW/BX610FW Office B40W/BX300F/BX300FW/BX310FN	55
ET0713		55
ET0714		55
ET0921		55
ET0922	EPSON Stylus C91,CX4300,T27	55
ET0923		55
ET0924		55
ET0731		AR
ET0732	EPSON Stylus C79/C90/C92/C110/CX3900/CX4900/CX4905/CX5500/CX5600/CX5900/CX6900F/CX7300/CX8300	45
ET0733		45
ET0734		45
ET073N-B		AR
ET073N-C	EPSON stylus C79/C90/C92/C110/CX3900/CX3905/CX4900/CX4905/CX5500/CX5505/CX5600/CX5900 /CX6900F/CX7300/CX7310/CX8300/CX9300F	69
ET073N-M	T10/T11/T13/T20/T21/T23/T24/T30/T33/T40W/TX100/TX105/TX110/TX111/TX115/TX200/TX209/TX210/TX213/TX220/TX300F/TX400/TX409/TX410/TX 550W/TX600FW/TX610FW	69
ET073N-Y		69
T01171N	Stylus T23/T24/TX105/TX115	69
ET073N C/M/Y		69
ET090N	Stylus T20/T21/TX100/TX110/TX111	69
ET073N C/M/Y		69
ET007-N	EPSON Stylus Photo 780,785EPX,790,825,870,875DC,875DCS,890,895,900, 915, 1270,1280,1290,1290S	45
ET009-C	EPSON Stylus Photo 900,1270,1280,1290,1290S	45
ET017-N	Stylus Color 680,777,777i Epson 1000ICS	35
ET018-C		35
ET019-N	EPSON Stylus Color 880,880i	35
ET020-C		35
ET026-N	Epson 810/820/830/925/C50	35
ET027-C		35

ET028-N			35
ET029-C	EPSON Stylus C50,C60,C61,CX3100		35
ET036-N			35
ET037-C	EPSON Stylus C42UX,C44UX,C46		35
ET038-N			45
ET039-C	EPSON Stylus C41,C41UX,C43UX/SX,C45,CX1500,CX1500V		45
ET040-N			35
ET041-C	EPSON Stylus C62,CX3200		35
ET066-N			35
ET067-C	EPSON Stylus C48		35
ET1001-N	EPSON Stylus SX510W Stylus office B40W/BX600FW/BX610FW/SX515W/SX600FW/SX610FW		75
ET711H	EPSON Stylus D120/DX7400/DX7450/DX8400/DX8450/DX9400F/SX205/SX215 SX218/SX400/SX415/SX515W/SX600FW/SX610FW office B1100/B40W/BX300F/BX310FN/BX600FW/BX610FW		75
ET1002			75
ET1003	Stylus SX510W Stylus office B40W/B1100/BX310FN/BX600FW BX610FW/SX515W/SX600FW/SX610FW BX610FW/SX515W/SX600FW/SX610FW		75
ET1004			75
ET0187-N/050	Stylus Color 400/440/460/500/600/610/640/660/670/ = Stylus Photo 700/710/720/750/750 FOR WEB/1200/EX/EX2/EX3/IP-100		45
ET0193-C	Stylus Photo 700/710/720/750/750 FOR WEB/1200/EX/EX2/EX3/IP-100		65
ET0189/051-N	Stylus Photo 400/440/460/600/610/640/660/670/740/760/800/850/860/1160/1520 = Stylus Scan 2000/2500/2500 Pro		AR
ET089/191-C			65
ET0321	EPSON Stylus C70, C70+, C80,C80N,C80WN,C82,C82N, C82WN,CX5100,CX5200,,CX5300,CX5400		35
ET0322			35
ET0323	EPSON Stylus C70, C70+, C80,C80N,C80WN		35
ET0324			35
ET0321			35
ET0422			35
ET0423	EPSON Stylus C82,C82N,C82WN,CX5100,CX5200,CX5300,CX5400		35
ET0424			35
ET0441			55
ET0442			55
ET0443	EPSON Stylus C64,C66,C84,C84N,C84WN,C86,CX3600,CX3650,CX4600,CX6400,CX6600		55
ET0444			55
ET0461			35
ET0471	EPSON Stylus C63,C65,C83,C85,CX3500,CX4500,CX6500		35
ET0473			35
ET0474			35
ET0481			49
ET0482			49
ET0483			49
ET0484	EPSON Stylus Photo R200,R220,R300,R300M,R320,R340,RX500,RX600,RX620,RX640		49
ET0485			49
ET0486			49
ET0491			65
ET0492			65
ET0493			65
ET0494	EPSON Stylus Photo R210,R230,R310,R350,RX510,RX630,RX650		65
ET0495			65
ET0496			65
ET0551			65
ET0552			65
ET0553	EPSON Stylus Photo RX420,RX425,RX520,R240,R245		65
ET0554			65
ET0601			35
ET0602			35
ET0603	EPSON Stylus C88,CX3800,CX3810,CX4200,CX4800,CX5800F,CX7800		35
ET0604			35
ET0611			55
ET0612			55
ET0613	EPSON Stylus D68,D88,D88+,DX3800,DX3800+,DX3850,DX3850+,DX4200,DX4250, DX4800,DX4800+,DX4850,DX4850+		55
ET0614			55
ET0631			45
ET0632			45
ET0633	EPSON Stylus C67,C87,C87 Plus,CX3700,CX4100,CX4700,CX5700F,CX7700		45
ET0634			45
ET0771			75
ET0772			75

ET0773	EPSON Stylus Photo R260/R280/R380 RX580/RX595/RX680 Artisan 50New	75
ET0774		75
ET0775		75
ET0776		75
ET0801	EPSON Stylus Photo P50,T59, R265/270/285/290/360, RX560/585/610/650/685, PX650W/660/660+/700W/710W/720WD/730WD/800FW/810W/820FWD/830FWD, TX659/710W PX650W/660/660+/700W/710W/720WD/730WD/800FW/810W/820FWD/830FWD TX659/710W	75
ET0802		75
ET0803		75
ET0804		75
ET0805		75
ET0806		75
ET0811	EPSON Stylus Photo T50/R270/R290/R390/RX590 RX610/RX690/1410/TX650/700W/710W/800FW/810FW Artisan 635/725/730/835/837	75
ET0812		75
ET0813		75
ET0814		75
ET0815		75
ET0816		75

EPSON®

TONER EPSON



Référence	Désignation	Prix TTC
LE 1200	Toner Epson AcculaSer M1200	1790
LEM 2000/2010	Epson AcuLaser M2000D/M2000DT/M2000DTN(EU)/E2010D/M2010DN(HK/TW/SG)	1090
LEC 1100 Black	Epson AcuLaser C1100/1100N/CX111N/11NF	990
LEC 1100 cyan		990
LEC 1100 magnta		990
LEC 1100 Yellow		990
LEC 1600 Black	Toner Epson AcculaSer LM1600/1650/1680/1690TD/CX16NF	2390
LEC 1600 Cyan		2390
LEC 1600 Magenta		2390
LEC 1600 Yalooow		2390
LE50010/N	Toner Epson EPL 5700/5700L/5800PTX/5800TX	1790
LE50087/N	Toner Epson EPL 5900L/6100/6100L	1790
LE50167	Toner Epson EPL 6200/6200L	AR

EPSON®

PHOTOCONDUCTEUR EPSON



Référence	Désignation	Prix TTC
LE514055B	Drum EPL 5900/6100	2490
LE51055A	Drum EPL 5700/5800	2490
SFS51099	Drum EPL 6200/6200L	AR
DC1100	Drum Epson C1100	ND

EPSON®

RUBAN EPSON



Référence	Désignation	Prix TTC
RBLQ300K	Ruban epson LQ300K/LX300	110
RBLQ1170	Ruban epson LQ1600K/1170	120
RBLQ2090	Ruban epson LQ2090	ND
RBLQ2170/2080	Ruban epson LQ2170 LQ2080/1600III	145
RBDXF5/8	Ruban epson DFX5000/8000	250
RBLQ590	Ruban epson LQ590/FX890	ND



CARTOUCHES HP



Référence	Désignation	Prix TTC
HP920B XL	HP Officejet 6000 /6500/6500 Wireless/6500A /7000/7500/7500A	350
HP920C/MY		350
HP29A	HP DeskJet 600/600Lotus/600C/D/K/610CL/612C/630C/632C/640C/642C/648C/656C/658Z/660 Lotus/660C/D/K/J/660CSE/670C/670TV/672C/680C/682C/690C/692C/K/693C/694C/695C/697C = Office Jet 500/520/570/580/590/600/610/630/635/700/710/720/725/750 =Desk Writer 600/660C/680C/690C/694C = Apple Color StyleWriter 4100/4500 = PSC 300/370/380 = Fax 910/920	690
CH49A/N	HP Deskjet 350c/350cbi/600/600Lotus/600c/600k/610c/610cl/612c/630c/632c/640c/642c/648c/656c/656c/660c/660cse/660c Lotus/660d/660j/660k/670c/670tv/672c/680c/682c/690c/691c/692k/693c/694c/695c/695cci/697c = Deskwriter 600/660/660c/680/680c/690c/694c = Officejet 500/520/570/580/590/600/610/630/635/700/710/720/725 = Priter/Scanner/Copier 300/370/380 = Apollo	690
CH14A/20 N	HP Deskjet 610c/610cl/612c/640c/656c/630c/632c/642c/648c/656c/656c/660c/660cse/660c Apollo P2100u/2150u/2200/2250 = Fax 925 Series	690
HP26A	HP DeskJet 200cci/plus400/400L/420/420c/500j/500/500c/505c/505j/505k/510/520/540/540c/550c/560j/560k = DeskWriet c/510/520/540/550c/560c = Designjet 200/220/600 = SAMPO FT-600/FT-660/FT-663 = Officejet LX/300/310/320/330/350 = Printer/Scanner/Copier 370/380 = Fax 200/300/310/700/750/800/900/950 = Apollo P-1200/1220/1250/1250i = Panasonic Fax UG300/321/UF332a	690
HP27A XL	HP Deskjet 3300/3400/3550/3535/5550/3320/3323/3325/3420/3425 Officejet	690
HP28A	4110/4110v/4110xi psc 1210/1210v/1210xi	1290
HP56A	HP Photo Smart 100/130/230/230v/230xi/7150/7350/7550/7200/7260/7400/7450/7600/7700/7755/7900/7960/7960w/7760/7760v/7660/7660v/7660w/ 245/245v/245xi/145/ 145v/145xi = DeskJet 450/450cbi/450wb/5100/5550/5150/5150w/5500/5650/5850/9600/9650/9670/9680 = PSC	690
HP57A	1100/1110/1210/1210v/1210xi/1315/1350/1350v/1350xi/2110/2110v/2110xi/2105/2108/2115/2150/2175/2175v/2175xi/2210/2410/2410v/2410 xi/2420/2510 = OfficeJet 4110/4125/5510/6110/6110xi = Digital Copier printer 410 = PSC 1350/1350x/1350xi	1290
HP45D XL	HP Deskjet 710C/712C/720C/722C/820C/830C/832C/850C/855C/870C/880C/882C/890C/895C/930C/932C/935C/950/950C/952C/955C/960C/970C /980CXI/990CXI/995C/100C/1100C/1120C/1125C/1220C/1180C/1600C/1600CM/1600CN/6122/9300 == DesignJet 700/750C/750C PLUS/755CM == OfficeJet R40XJ/R45/R60/R65/R80/T45/T65XI/G55XI/G85XI/G95/K60/K80 - Pro 1150/1150C/1170/1175 series == PhotoSmart P1000/P1100/P1100CXI/1115/1215/1215VM/1218XI/1315 - Color Copier 110/120/140/145/150/155/160/170/180/210/210LX/260/270/280/290 CopyJet CopyJet M	690
HP78D	HP DesignJet 920C/920cxi/920c/930c/930cm/930 Photo/932c/935c/940c/940c/940c/948c/950c/952c/955c/960c/960cxi/960cse/990cxi/995c/1220c/1220cps/1220cse/1220cxi/1180c/3820/612 2/9300/Professionnels series; PSC 750/750xi/950; Color Copier 180/190/280/290 == OfficeJet G55/G85/G85XI/G95/K60/K60XI/K80/K80XI/V40/V40XI/5110 == Photo Smart P1000/P1100/P100XI/1115/1215/1215VM/1218/1218XI/1315	1290
HP23D	HP Deskjet 710/712c/720/720c/722c/810C/812C/815C/830C/832C/890C/882C/890C/895C/895CXI/1220C/1120CSE/1120CXI/1125C/PSC500 - HP Officejet PRO1170/1175C R40/R45/R60/R65/R80/T45/T65 = Color copieur 140/145/150/155/160/170/180/190/260/270/280/290	990
HP15D XL	HP 810C/825//840C/842C/845C/845CVR	690
HP17D	HPDeskjet 825C/825CVR/840C/842C/843C/845C/845CVR	990
HP21A XL	HP Deskjet 3910/3915/3918/3920/3930/3930V/3938/3940/3940V/D1311/D1320/D1330/D1341/D1360/D1368/D1455/D1460/D2330/D2360/D2430/D2460/ F370/F380/F2110/F2120/F2180/F2187/F2224/F2280/F4140/F4172/F4180/F4185/F4190 = PSC	890
HP22A XL	1400/1401/1402/1403/1406/1408/1410/1410V/1410XI/1415/1417 = Officejet 4315/4355/5605/5608/5609/5610/5610V/5610XI/5615/J3608/J3680/J5508/J5520/ = FaX 1250/3180 /1000-J110 /1050/2050/2050s/	1390
HP130 (596/130/339)	HP DeskJet 5740/5743/5745/5748/5940/5943/6540/6540D/6620/6840/6940/6943/6980/6983/9800/9860 == OfficeJet 7210/7210xi/7310/7310xi/7410/7410xi = Photo Smart 2575/2605/2610/2710/8150/8150x/8150xi/8450/8450Gp/8450V/8450Xi/8750/8750gp = PSC 2610/2710	990

HP134 (97/134/344)	hp Deskjet Officjet 6210/6210v/6210xi/6215/7210/7210xi/731/7410 2575/2605/2610/2710/325/335/375b/385/428/475/8150/8450/8750 1600/1610/1613/1615/2350/2355/2610/2710	460/5740/5743/5745/5748/5940/6620/6840/6940/6943/6980/6983/9800/9860 Photosmart Psc	990
HP131 (94/131/338)	HP DeskJet 460/5740/6540/6540D/6620/6840/9800/9800D = OfficeJet 6210/6210v/6210xi/6215/7310/7310xi/7410/7410xi/ = Photo Smart 2610/2710/8050/8150/8150v/8150xl/8450/8450GP/8450v/8450xi ; 1510/1513S/1610/2350/2355/2355v/2355xi/2610/2710	PSC	990
HP135 (95/135/343)	Deskjet 460/5740/5940/6540/6540d/6620/6840 = Officejet 6210/6215/7310/7310xi/7410 = 2575/2610/2710/325/335/375/375b/385/475/8050/8150 = Psc1510i/1513s/1610/2350/2355i/2610/2710	Photosmart	990
HP60/121BK/300/ XL	HP Deskjet D2500/D2560/D2563/F4200/F4240/F4272/F4275/F4280/F4283		1290
HP60/121C/300C/ XL			1290
CH10BK/C4844A	HPDesignjet 100/100plus/110plus/110plus nr/500/500ps/70/800/800ps/815mfp/820mfp Business Inkjet 1000/1100/1100D/1100Dtn/1200/1200d/1200dn/1200dtn/1200dtwn/cp1700/cp1700D /cp1700p 2000c/2000cn/2200/2200se/2200xi/2230/2250/2250tn/2280/2280tn/2300/2300Dtn/2300n 2500c/2500cm/2600/2600Dn/2800/2800dt/2800dtn/3000/3000n/3000Dtn Officejet 9100/9110/9120/9130 OfficeJet Pro K850/k850dn		290
CH82 C/M/Y	HP Designjet 10ps/20ps/120nr/50ps/500/500ps/500Plus/510/ 800/800ps/815/815mfp/820/820mfp		290
CH10BK/C4844A	HPDesignjet 100/100plus/110plus/110plus nr/500/500ps/70/800/800ps/815mfp/820mfp Business Inkjet 1000/1100/1100D/1100Dtn/1200/1200d/1200dn/1200dtn/1200dtwn/cp1700/cp1700D/cp1700ps 2000c/2000cn/2200/2200se/2200xi/2230/2250/2250tn/2280/2280tn/2300/2300Dtn/2300n 2500c/2500cm/2600/2600Dn/2800/2800dt/2800dtn/3000/3000n/3000Dtn Officejet 9100/9110/9120/9130 OfficeJet Pro K850/k850dn		290
CH11 C/M/Y	HP Business Inkjet 1100/1200/2200/2230/2250/2280/2300/2600/3000/cp1700/ = Color Inkjet cp1700/ = DesignJet 100/110/500/800/815/ = Office Jet 9110/9120/9130/Pro K850		290



Référence	Désignation	Prix TTC
LH435A/436A/285A/NN/C UNI	HP LaserJet P1005/P1006 HP LaserJet P1100/P1102/P1102W/P1104/P1104W/P1106/P1106W/P1107/P1107W/P1108/P1108W/P1109/P1109W HP Laserjet pro M1132/M1210/M1212nf/M1213nf/M1214nf/M1216nf/M1217nf/M1218nf/M1219nf HP LaserJet P1503/P1504/P1505/P1506/P1503n/P1504n/P1505n/P1506n HP LaserJet M1120/M1120n/M1120a/M1120h/M1120w/ M1522n/M1522nf/M1522nt Canon LBP3018/3010/3100/3150/ LBP6018/6000/ LBP-3250	790
LH2612A/UNI/CRG103/303 /703/FX9 FX10/L90/C104NN	HP LaserJet 1010/1012/1015/1018/1022/1022N/1022NW/1020/3015MFP/3020MFP/3030MFP/3050MFP/3052MFP/ 3055MFP/3050Z/M1005MFP Canon Fax L-100/L-120, FaxPHONE 120, MF4150,FAX L905A, I-Sensys 4120/4150MF/4660PL/MF4690PL Canon LBP 2900, Canon LBP 3000,MF4350	790
2613A	HP Laserjet 1300/1300n/1300xi	990
3906A	HP LaserJet 5L/5ML/6L/6LSE/6LXI/3100/3150 Series LBP-440/460/465/660	Canon 990
4092A	HP LaserJet 1100/1100SE/1100XI/1100A/1100A SE/1100A XI/3200/3200SE 800/810/1110/1120	Canon LBP- 990
4096A	HP2100N/2200DN/2100/2200 LBP-470 LBP-1000 LBP1310	CANON 1690
7115A	HP LaserJet 1000/1005/1200/1200N/1200SE/1220/1220SE/ 3300MFP/3320n MFP/3320MFP/3330 MFP	Canon LBP 1210 AR
7551A	HP LaserJet P3005/P3005D/P3005N/P3005DN/P3005X,M3027MFP/M3027XMFP/M3035MFP/M3035XS MFP	1990
436A	HP LaserJet P1505/P1505N/M1120/M1120N/M1522N/M1522NF Canon LBP-3250	690
5949A/7553A	HP Laser jet 1160/1320/3390/3392 HP Laser Jet P2010/P2015/P2014/M2727nf 3300/LBP3310/3360/3370	CANON LBP 1290
505	HP P2030/2035/2035n/P2050/2055d/2055n/2055x LBP6300dn/LBP6650dn/MF5870dn	Canon AR
255	HP Laserjet Enterprise P3015/P3015d/P3015dn/P3015x LBP6750dn	Canon AR

540A/CE320A/CF210X	HPColor laserJetCP1213/CP1214/CP1215/CP1216/CP1217/CP1513n/CP1514n/CP1515n/CP1516n/CP1517ni/CP1518ni/CP1519ni/HP Color laserJet CM1300MFP/CM1312MFP Series/ HP LaserJet Pro 200 color M251nw HP LaserJet Pro 200 color M276n/nw	1890	
541-542-543	HP LaserJet ProCM1411fn/CM1412tn/CM1413fn/CM1415fn/CM1415fnw/CM1416fnw/CM1417fnw/CM1418fnw HP LaserJet ProCP1521/CP1522/CP1523/CP1525/CP1525nw/CP1526nw/CP1527nw/CP1528nw Canon LBP5050/8050 /MF8230CN	1890	
310A	HP LaserJet Printer CP1025/Cp1025NW	1190	
311-314		1190	
320A	HP LaserJet ProCM1411fn/CM1412tn/CM1413fn/CM1415fn/CM1415fnw/CM1416fnw/CM1417fnw/CM1418fnw HP LaserJet ProCP1521/CP1522/CP1523/CP1525/CP1525nw/CP1526nw/CP1527nw/CP1528nw	1990	
321-323		1990	
530A	HP Color LaserJet CP2020/CP2025/CM2320 LaserJet 2410, 2420, 2420d, 2420dn, 2420n, 2430dn, 2430n, 2430tn, 2430n	HP	2490
531-533	Canon LBP 7200/7200cn/ic MF8330/8350Cdn		2490
7553A	HP LaserJet M2727nf MFP, P2014, P2015, P2015d, P2015dn, P2015n, P2015x		1390
6511A	HP LaserJet 2410/2410n/2420/2420n/2430/2430n 3410/3460	Canon LBP	2690
6511X	HP LaserJet 2410/2410n/2420/2420n/2430/2430n 3410/3460	Canon LBP	2990
2610A	HP2300/2300N/2300DN/2300D/2300DTN		2190
4127A	HP LaserJet 4000, 4000N, 4000T, 4000TN, 4000se, 4050, 4050N, 4050T, 4050TN, 4050se 1760, 1760e, 52X, 2460N	CANON LBP- BROTHER HL-2460, HL-	2390
4129A	HP LaserJet 5000/5000g/5000GN/5000LE/5100/5100DTN/5100TN LBP-840/850/870/880/910/1610/1620/1810/1820, Canon Image Class 2200/2210/2220/LP-3000/3010	Canon	3890
4182A	HP LaserJet 8100, 8100DN, 8100N, 8150, 8150 MFP, 8150dn, 8150hn, 8150n, Mopier 320, ImageCLASS 4000, 4000E, 4000ED, ImageRUNNER 3250, LBP-1910, 3260, 72X, 950	CANON	3890
8061A	HP LaserJet 4100, 4100MFP, 4100dn, 4100n, 4100tn, 4101MFP		2890
1338/1339A	HP LaserJet 4200/4300/4250/4350/4345 Series		3490
2624A	HP LaserJet 1150 (2500 Pages)		1290
2624X	HP LaserJet 1150 (6000 Pages)		1690
HP6000/1/2/3	HP Color LaserJet 1600/2600/2600N/2605DN/2605DTN = CANON LBP 5000		2390
HP6460/1/2/3	HP Color LaserJet 4730mfp/4730xmf - HP Color LaserJet CM4730f/CM4730fm/CM4730fsk		4790
HP3960/1/2/3	HP Color LaserJet 2550L/2550Ln/2550n HP Color LaserJet 2820/2840/2830 = 5200	Canon LBP	ND
HP2670/1/2/3	HP Color LaserJet 3500/3500n/3550 - HP Color LaserJet 3700/3700n/3700dn/3700dtn		4590
HP9730/1/2/3	HP Color LaserJet 5500/5500DN/5500HDN/5500N/5550/5550DN/5550DTN/5550HDN/5550N		6890
HP9720/1/2/3	HP Color LaserJet 4600/4600n/4600dn/4600dtn/4610n - HP Color LaserJet 4650/4650n/4650dn/4650dtn/4650hdn Canon LBP 2510		5890



Référence	Désignation	Prix TTC	
PGI550BK	PIXMA MG5450/MG5550/MG5650/MG6350/MG6450/MG6650/MG7150/MG7550/Ip7250/MX925/MX725/IX6850/IP8750	AR	
CL551BK		79	
CL551C/M/Y		AR	
C21/24BK-N	CANON bjc250j/323f/400j/411f/420j/430j/455j/2000/2010/2100/2110/4310/4400/4500/4550/4650/5000/5100/5500 = b210c/b215c/b230c/b380if = Faxphone b740 c20/c30/c50/c70/c75/c80/c530/c545/c555/c560/c635/c2500/c3000/c3500/ c5000/c5500/s100/b380if/cfx-b380if,5200/5300 Series/i250/i255/i320/i350/i355/ip1000/ip1500/ip2000/i450/i470d Series Mpc190/Mpc200 = Imageclass Mp360/Mp37/Mp390	Fax Multipass Smartbase	45
C21/24C-C		45	
C3EB	CANONBJC-3000/6000/6100/6200/6200S/6500 - PIXMA iP3000/iP3300/iP4000/iP4000R/iP4200/iP4300/iP5000/iP5200 iP5200R/iP5300/iX4000/iX5000/MP500/MP510/MP530/MP600/MP600R MP750/MP760/MP780/MP800/MP800R/MP810/MP830/MP950 PIXIIS MP770/MP790/iP3100/iP4100/iP4100R/i550v/i550v/i560/i6100/i6500 / i850/i860 / i845/i8400 / S400SP/S400v		49

C3EC-M-Y	S450/S500/S520/S520x/S530D/S600/S630/S750/S4500 SmartBase MP700/MP700 Photo MP730/MP730 Photo/MPC400/MPC600F MultiPASS C100	49
CL18BK	CANON PIXMA iP4200,iP4300, iP4500, iP5200,iP5200R,iP5300,iP6600D,iP6700D,MP500, MP530, MP600,MP600R, MP800,MP800R,MP810,MP830,MP950,MP960,Pro9000	89
CL18C/M/Y		89



Référence	Désignation	Prix TTC
LC125/325/725/925	Canon LBP6018/6000 = HP LaserJet P1100/P1102/P1102W/P1104/P1104W/P1106/P1106W/P1107/P1107W/P1108/P1108W/P1109/P1109W HP Laserjet pro M1132/M1210/M1212nf/M1213nf/M1214nf/M1216nf/M1217nf/M1218nf/M1219nf	ND
LC119/319/719	Canon LBP6300dn/LBP6650dn/MF5870dn = P2030/2035/2035n/P2050/2055d/2055n/2055x	HP 1490
LC128/328/728	Canon ic MF4420n/4412/4410 Canon ic D520 4452/4450 Canon ic MF 4550d/4570dn	Canon ic MF ND
LC129/329/729BK	Canon LBP 7010C/7018C LaserJet Pro CP1025	990
LC129/329/729C		990
LC129/329/729M		990
LC129/329/729Y		990
T250X	Canon LBP 7700C/7750Cdn Color LaserJet CP3525/CP3525X/CP3525DN/CP3525N/CM3530/CM3530FS	4290
T251X		4290
T252X		4290
T253X		4290
LC118/318/718BK	Canon LBP 7200/7200cn/iC MF8330/8350Cdn; LASERJET 2025	2490
LC118/318/718C		2490
LC118/318/718M		2490
LC118/318/718Y		2490
LC116/316/716BK	Canon LBP 5050/5050n/iC MF8030/8050 LASERJET C305	1790
LC116/316/716C		1790
LC116/316/716M		1790
LC116/316/716Y		1790
FX8	CANON LBP2500/2700/3200	ND
OR-LCE16/E30/31/40	CANON FC200/FC210/FC220/FC204/FC224/FC230/FC310/FC330/FC530/ PC740/PC760/PC770/PC780/PC860/PC890	2290
LCEP26/27/ORGU/X25	CANON LBP3200/imageclass mf5530/mf5550/mf5630/mf5650/mf5750/3110/3112/mf5770	1290



Référence	Désignation	Prix TTC
CB11/16/38/60/975/980/99	Brother DCP- J140W/145C/165C/185C/195C/197C/365CN/375CW/385C/390CN/395CN/ 535CN/585CW/595CN/J715W/6690CN/6690CW/J515N/J715N MFC-250C/255CW/257CW/J270W/290C/295CN/490CN/490CW/495CN/585CW/J615W/J615W WIFI/J615N/ 670CD/670CDW/675CD/675CDW/695CDN/695CDWN/J700D/J700DW/735CD/735CDN/790CW/795CW/J800D/J800DW/J805D/J805DW/J8 50DN/J850DWN/J855DN/ J855DWN/930CDN/930CDWN/935CDN/ 935CDWN/J950DN/J950DWN/990CW 5490CN/5490CW/5890CN/6490CN/6490CW/6890CDW/ 6890CN DCP-J125/J315W/J515W/J140W MFC-J265W/J410/J415W/J220	79
CB11/16/38/60/975/980/99		79
CB11/16/38/60/975/980/99		79
CB11/16/38/60/975/980/99		79
CB103BK	Brother MFC-J4310DW/J4410DW/J4510DW/J4610DW/J4710DW/J6520DW - MFC-J285DW/J470DW/J475DW/J650DW/J870DW/J875DW/J6920DW/DCP-J152W MFC-J245/J450DW/J6720DW	89
CB103C		89
CB103M		89
CB103Y		89
CB123BK		AR
CB123C		AR
CB123M	MFC-J4410DW/J4510DW/J4610DW/J4710DW/J470DW/ J6920DW DCP-J4110DW/J132W/J152W/J552DW/J752DW	AR

CB123Y		AR
CB39/60/975/985BK		79
CB39/60/975/985C	Brother DCP-J125/J315W/J515W/J540W - MFC-J265W/J410/J415W/J220	79
CB39/60/975/985M		79
CB39/60/975/985Y		79
CB12/71/73/75/400/1220/1		89
CB12/71/73/75/400/1220/1	Brother MFC- J6910CDW/J6710CDW/J5910CDW/J825N/J955DN/J955DWN/J705D/J705DW/J710D/J710DW/J810DN/J810DWN/J825DW/J840N/J625DW/J860DN/J860DWN/J960DN-B/J960DN-W/J960DWN-B/	89
CB12/71/73/75/400/1220/1	J960DWN-W/J432W/J430W/J6910DW/J6710DW/J5910DW/J6510DW/J435W/J835DW/J280W/J425W	89
CB12/71/73/75/400/1220/1	DCP-J525N/J540N/J740N/J925N/J525W/J725DW/J925DW/J940N-B/J940N-W	89



TONER BROTHER



Référence	Désignation	Prix TTC
LBTN1000/1030/1050/1060	Brother HL-1110/1111/1118/MFC-1810/1811/1813/1818/ DCP-1510/1511/1518	890
LBTN450/2220/2225/2250/2	BROTHER DCP7060D, DCP7065DN, HL2220/2230/2240/2240D/2250/2250DN/2270DW, MFC7360N, MFC7460DN, MFC7860DW	AR
LBTN580/3170/3175/3185/3	Brother HL5240/5250DN/5250DNT/5270/5280DW MFC8460N/8860DN DCP8060	1390
LBTN670/4100/4150/47J/N	Brother HL6050D/6050DN	1490
LBTN2010/2030/2060/2080/	Brother HL-2130/DCP-7055	1390
LBTN4150HBK/N(TN315/325/345/375/395BK	BROTHER HL-4140CN,HL-4150CDN,HL-4570CDWT,HL-4570CDW, MFC-9465CDN,MFC-9560CDW,MFC-9970CDW	1890
LBTN4150C/N(TN315/325/345/375/395C		1890
LBTN4150HM/N(TN315/325/345/375/395 M		1890
LBTN4150HY/N(TN315/325/345/375/395Y		1890
LBTN3040BK/N(TN210/230/240/270/290BK		BROTHER MFC-9010CN ,HL-3070CW,HL-3040CN,MFC-9120CN,MFC-9320CW
LBTN3040C/N(TN210/230/240/270/290C	1590	
LBTN3040M/N(TN210/230/240/270/290M	1590	
LBTN3040Y/N(TN210/230/240/270/290Y	1590	



PHOTOCONDUCTEUR BROTHER



Référence	Désignation	Prix TTC
LBDR210/230/240/270/290/NN	Brother HL3040CN/3070CW/MFC9010CN/9120CW/9320CW	1990

SAMSUNG

TONER SAMSUNG



Référence	Désignation	Prix TTC
LSML-1210	ML-1010/1020M/1210/1220M/1250/1430, SF-515/530/531P/535E/5100/5100P, Msys-5100p, ML-808; Phoser 3110/3210, Workcenter pro 580; E210	1990
LSML -1610	ML1610/ML2010/SCX4521F; 1100	1590
LSML-T108S	ML 1640/1641/2241/2240	1790
TS1660	LT104/ML1660/1665/1675/SCX3200	AR
LSML-1710	ML-1510/1520/1710/1750	1690

LSML-T105L	ML-1916K/1915K/1910K/2525K/2580NK/, SCX-4610K/4605K/1600K/4623K/4623FK/4623FN: CF-650/650F; ML-2525/2525W; SCX-4600/4623F, SF-650/650P; ML-2540	1790
LSML-2150	ML2150	2690
TS2250	ML2250/2251N/2251NP/2252W	1890
LSML-4600/4100	ML-1911/1910/2525/2581/2580/SCX4600/4601/4606/4623/CD-650	1790
LSCX4200	SCX4200	1490
LSML-T109	SCX4300	1590
SML4500	ML4500	1890
SCX4520	SCX4520	1890
SCX4720	SCX4720	2890
SML5800	ML5800	2490
LSCLP300BK	Samsung CLP-300/300N,Samsung CLX-2160/2160N/2161K/2161NK/3160N/3160FN	590
LSCLP300C		590
LSCLP300C		590
LSCLP300C		590
LST409BK	Samsung CLP310N/CLP315/CLP315W/CLX3175FN/CLX3175FW	2490
LST409C		2490
LST409M		2490
LST409Y		2490
LSK510BK	LaserCouleur CLP-510/560/500	3890
LSK510C		3890
LSK510M		3890
LSK510Y		3890

LEXMARK™

TONER LEXMARK



Référence	Désignation	Prix TTC
LLE210/220	Lexmark Optra E210/E220 Séries	1690
LLE250	Lexmark optra E250/E350/E352 séries	2190
LLE230/232	Lexmark optra E330/E332/E230/E232/E332n/E332TN/E232T/E234/240/340/342	1990
LLE450 A	Lexmark E450/450N/450DN	1990



TONER KYOCERA / MITA



Référence	Désignation	Prix TTC
TK17	Kyocera MITA FS-1000/1000+/1010/1050/1500/1020	890
TK110	Kyocera MITA 1016/ fs-720/820/920/1116MFP	890
LKTK 120/122	Kyocera MITA fs-1030 series	1390
TK130	Kyocera MITA fs-1300d/1350dn/1028/1128	AR
TK113	Kyocera MITA FS-1016	ND
TK418	Kyocera MITA FS-1620/1650/2050	1990
LK428H	KM1635/2250	2990
LK435/437/439/458/448H	Kyocera MITA taskalfa 180/220/181/221	2990
TK1130/1132	Kyocera FS-1030MFP/FS-1130MFP	1290

TK1140	Kyocera MITA 1035MF/1135MF	AR
LK1525/1530	Kyocera Mita km-1525/1530/2030	1990

OKI

TONER OKI



Référence	Désignation	Prix TTC
LOB4600	OKI B4600/4600N	1890
LOB410	OKI B410/430/440	1890

DELL

TONER DELL



Référence	Désignation	Prix TTC
LDB1160	DELL B1160/B1160W	2950
TS1610	ML1610/DELL 1100	1590

Obs

Obs

Obs

Obs

Obs